

PARTS LIST

- 1 - Cage and Wall Bracket Assembly
- 1 - Canopy (attached to cage)
- 4 - Lens Panels
- 1 - Spindle
- 1 - Parts Bag Containing:
 - 1 - Decorative Finial
 - 1 - ½" Long Steel Nipple
 - 1 - Locknut
 - 2 - #8/32 x 1" Knurled Brass Screws
 - 1 - Universal Mounting Plate
 - 1 - Green Ground Clip

ASSEMBLY INSTRUCTIONS

CAUTION: TURN POWER OFF AT MAIN BREAKER PANEL OR FUSE BOX PRIOR TO THE ELECTRICAL HOOKUP OF THIS OR ANY ELECTRIC FIXTURE!

1. - Screw the locknut to one end of the ½" steel nipple and insert the nipple through the hole in the top of the canopy.
2. - Attach the finial to the nipple by finger tightening in a clockwise direction.
3. - Push spindle on wall bracket base.

NOTE: If the part does not push easily or completely into the base, apply a few drops of any household lubricant to the inside lip of the spindle.

LENS PANEL INSTALLATION

(The raised beveled portion of the lens panels are to face to the outside of the lantern cage.)

1. - Insert the small end of a lens panel into one of the four slots inside the cage.

NOTE: All but the final lens panel will fit into position easily. After inserting the final panel, it will be necessary to apply a downward pressure at the top of the panel to snap it into position.
2. - After all four panels have been installed, apply a downward pressure on all the panels to assure proper seating of the lens.

INSTALLATION INSTRUCTIONS

(For ease of installation, two people may be used for step #2.)

1. - Affix the universal mounting plate to an approved splice box, making sure the two (2) threaded screw holes in the plate are level in a horizontal position. (Screws not provided for this operation)
2. - Using approved wire connectors (not furnished), connect the black wire of the lantern to the black incoming power wire; connect the white wire from the lantern to the white incoming power wire; and connect the green ground wire from the lantern to the incoming ground wire. RECHECK ALL ELECTRICAL CONNECTIONS FOR LOOSE OR EXPOSED WIRES!
3. - Insert the two (2) 1" long brass knurled screws provided through the holes in the bracket and fasten the lantern to the mounting plate on the splice box.
4. - Carefully install a 60 watt **maximum** incandescent bulb in the lantern socket; replace the canopy on the cage assembly.
5. - Turn the power on at the main control panel only after installation is complete!

ALWAYS CONNECT BLACK TO BLACK,
WHITE TO WHITE, AND BARE OR
GREEN GROUNDING CONDUCTORS

